



KULLANIM KILAVUZU

Akıllı Atlama İpi ŞİMART Uygulaması




www.smart.me

Ürün Tanıtımı




- LCD Ekran
 - Aç | Kapat | Sıfırlama Tuşu
 - Pil Kapağı
 - PVC Kaplı Çelik İp
 - Renkli LED Işık (bu fonksiyon sadece ana elcikte mevcuttur)
- Not: Pilleri yerleştirmek için ana elcikteki pil kapağını açın ve 2 Adet AAA LR03 1.5V pili yuvasına yerleştirin. Lütfen pillerin kutuplarının doğru yerleştirildiğinden emin olun.



Resimde gösterilen pil yerleştirme parçalarını kaybetmemeye özen gösteriniz, aksi takdirde ürününüz çalışmayacaktır.

Akıllı Atlama İpi Kurulumu



İp atlama elcikleri ve ip kutunun içerisinde ayrı ayrı paketlenmiştir. Ürünün kurulumunu yapmak ve ip uzunluğunu kendinize uygun biçimde ayarlamak için lütfen resimdeki adımları takip ediniz.

KULLANIM KILAVUZU AKILLI İP atlama – ŞİMART Uygulaması

Önemli Notlar

- Ürünü düşürmekten veya sertçe yer eçarpmaktan kaçının, aksi takdirde ürününüzde kullanıcı hatasından dolayı hasar meydana gelebilir.
- Akıllı Atlama İpi, elektronik bir aygıt olduğu için lütfen ürüne özen gösteriniz.
- Akıllı Atlama İpi, su geçirmez bir ürün değildir; bu nedenle elcikleri suya batırmayın veya yağmur yağarken ürünü dış mekanda kullanmayın, aksi takdirde dahili elektronik parçalarda kullanıcı hatasından dolayı hasar meydana gelebilir.
- Lütfen ürünü cıvalı zemin, ahşap zemin veya spor salonu zemini gibi düzlük alanlarda kullanın, pürüzlü yüzeyler için PVC kaplamasının ömrünü kısaltacaktır.
- İlk kullanımdan arıandan veya pilleri yenisiyle değiştirdikten sonra kayıtlı verilerde uyumsuzluk olması durumunda Akıllı Atlama İpi'ni, Şİmart uygulaması ile yeniden eşleştirmelisiniz.
- Yaralanma ihtimali bulunduğundan dolayı PVC kaplı çelik kablo ipiyle atarken dikkatli olun, ayrıca 10 yaşın altındaki çocukların ürünü bir yetişkin gözetiminde kullanması önerilir.

LCD Ekran

- Sayaç açmak için tuşa basın, ışık yanacaktır.
 - Modlar arasında geçiş yapmak için 2 saniye boyunca tuşa basılı tutun.
 - Mevcut moda verileri sıfırlamak için tuşa iki kere basın.
 - Cihazı sıfırlamak için 8 saniye boyunca tuşa basılı tutun.
- Not: 10 saniye boyunca işlem yapılmazsa LCD ekran ışığı sönecektir, cihaz 5 dakika sonra uykı moduna geçecektir. Tuşa tekrar basılması durumunda sayaç yeniden etkinleşecektir.

LED Renk Göstergesi

- Sayaç açık olduğunda LED ışıklar birer kere kırmızı, yeşil, ve mavi sırasıyla devir yaparak yanacaktır.
- Renklerin herbiri, ip atlayış hızınızın seviyesini temsil eder.
- Kırmızı: ≥200 rpm (devir sayısı/dakika)
 - Yeşil: 160 rpm (devir sayısı/dakika)
 - Mavi: 100 rpm (devir sayısı/dakika)

Uygulamanın Kullanımı

- Şİmart Uygulamasını, uygulama mağazalarından veya aşağıdaki QR kodunu tarayarak indiriniz.



- Telefonunuz Android işletim sistemiyse uygulamayı yükledikten sonra lütfen Bluetooth, GPS & Konum izinlerini etkinleştiriniz.
- Not: Uygulamayı, Bluetooth üzerinden bir cihaz ile eşleştirmek için, Android 6.0 veya üstü sürümlerde akıllı telefonların konum izinleri etkinleştirilmesi Google tarafından mecbur kılınmıştır.
- Daha fazla bilgi için ayrıca Google'ın resmi sitesine bakabilirsiniz: <https://source.android.com/devices/bluetooth/ble>
- Şİmart uygulamasını açın, oturum açma bilgilerinizi girin ve uygulamayı başlatın. Henüz kayıt olmadıysanız "Kaydol" butonuna basarak kayıt olabilirsiniz.
- Akıllı Atlama İpi, bağlantı modunda olması durumunda otomatik olarak eşleşecektir. Bağlantı durumunu kontrol etmek için uygulama içerisindeki arayüze göz atabilirsiniz.
- Arayüzdeki "Eklendi" bilgisi eşleşmenin başarılı olduğunu belirtir.
- Arayüzdeki "Eklenmedi" bilgisi eşleşmenin başarısız olduğunu belirtir. Bu sorunu çözmek için lütfen "+Cihaz Ekle" butonuna tıklayın ve manuel olarak cihazı ekleyin.
- Not: Eşleşme başarılı olduğunda LCD ekranın sol üst köşesinde "Bağlı" simgesi belirecektir.

KULLANIM KILAVUZU AKILLI İP atlama – ŞİMART Uygulaması

- İp atlamaya başlamak için uygulama içerisindeki arayüzde kullanmak istediğiniz atlama modunu seçiniz

Atlama Modları

- İstediğiniz modu seçmek için 2 saniye boyunca tuşa basılı tutun.
- Modları ayrıca uygulama üzerinden de seçebilirsiniz.

Serbest Atlama

- Serbest bir şekilde ip atlayın, herhangi bir süre veya sayı sınırı yoktur.



LCD ekranındaki simgesi resimde gösterilmiştir.

Zamanlı Atlama

- Serbest bir şekilde ip atlayın, herhangi bir süre veya sayı sınırı yoktur.
- Zamanlıya uygulama üzerinden ayarlayabilirsiniz.
- Akıllı Atlama İpi, uygulama olmadan kullanıldığında uygulamadaki zamanlayıcı bölümünde belirlenen en sonki geri sayım ayarını kullanacaktır.



LCD ekranındaki simgesi resimde gösterilmiştir.

Sayarak Atlama

- Toplam atlamak istediğiniz sayıyı belirleyiniz.
- Sayıyı uygulama üzerinden ayarlayabilirsiniz.



LCD ekranındaki simgesi resimde gösterilmiştir.

KULLANIM KILAVUZU AKILLI İP atlama – ŞİMART Uygulaması

Çevrimdışı Yedekleme Fonksiyonu

Uygulamayı çalıştırmadığınızda atlama verileriniz cihaz tarafından geçici olarak kaydedilecek ve yeniden bağlanıldığında veriler uygulama ile senkronize edilecektir.

Sayaç Kapatma | Sıfırlama

Elcik üzerindeki tuşa 8 saniye boyunca basılı tutun, sayaç kapanacaktır. Sayaç yeniden etkinleştirmek için tuşa tekrar basınız. Atlayış sayısını ve zamanlayıcıyı sıfırlamak istediğinizde tuşa iki kere basmanız yeterli olacaktır.

LED Işık Ayarları

Ana elcik üzerindeki LED ışığı, ip atladığımız zaman yanar. Mavi, Yeşil ve Kırmızı olmak üzere her bir renk sırasıyla varsayılan 100, 160, 200 rpm hızını temsil eder.

Kayıtlı Veriler

Akıllı Atlama İpi, sadece o güne ait yakılan kalorileri ve egzersiz süresini kaydetmekle kalmaz, aynı zamanda haftalık, aylık, ve yıllık olmak üzere daha uzun süreli verilerin kaydını tutar. Bu özellik gelişiminizi kıyaslamanız ve takip etmeniz için oldukça önemlidir.

Pil Ömrü

Akıllı Atlama İpi, normal kullanımda yaklaşık 180 gün dayanabilen AAA LR03 1.5V pil kullanmaktadır. (Günlük 15 dakikalık bir kullanım süresine göre hesaplanmıştır. Esas kullanım süresi ürünün kullanım sıklığına göre değişir). Pillerin dayanma süresi 350 gündür (deneylerimiz 25 °C sıcaklık ve %65 bağıl nem altında yapılmıştır). Düşük pil simgesinin ekranda belirmesi durumunda lütfen pilleri yenisiyle değiştiriniz. Akıllı Atlama İpi'ni uzun süre kullanmayacasanız lütfen pilleri çıkarınız. Ürünün uzun süre kullanılmaması durumunda içerisindeki AAA LR03 1.5V pilleri akabilir ve cihaza zarar verebilir.

Parametreler


Ebatlar	φ37,5 x 168mm
Ağırlık	180g
LCD Ekran	19,6 x 8,1mm
Pil	AAA LR03 1.5V x 2
Pil Ömrü	90 Saat
En Fazla Atlama	9999 kere
En Fazla Süre	99 dakika 59 saniye
En Az Atlama	1 kere
En Az Süre	1 saniye
Otomatik Kapatma	5 dakika



Atık elektrikli ürünler, evsel atıklarla birlikte atılmamalıdır. Lütfen uygun geri dönüşüm tesislerinde geri dönüştürün. Geri dönüşüm tavsiyesi için yerel yetkili makamlara veya satıcınıza danışın.


KULLANIM KILAVUZU AKILLI İP atlama – ŞİMART Uygulaması

USER MANUEL Smart Rope Skipping ŞİMART Application




www.smart.me

Product Introduction




- LCD Display
 - On/Off/Reset/Push Button
 - Battery Cover
 - PVC Coated Steel Rope
 - Multi-color LED Lights (this function is only available on the main hand grip)
- Note: To insert the batteries, open the battery cover on the main grip and insert 2 pieces AAA LR03 1.5V batteries into the battery slot. Please make sure the polarity of the batteries is correct.



Be careful not to lose the battery inserts shown in the picture, otherwise your product will not work. otherwise your product will not work.

Smart Rope Mounting



Skipping Rope hand grips and rope are packed separately in the box. Please follow the steps in the picture to install the product and adjust the rope length to suit you.

USER MANUEL Smart Rope Skipping – ŞİMART Application

Important Notes

- Avoid dropping the product or hitting the ground hard, otherwise your product may be damaged due to user error.
- Since the smart jump rope is an electronic device, please take care of the product.
- Smart rope is not a waterproof product; therefore, do not immerse the hand grips in water or use the product outdoors when it is raining, otherwise internal electronics may be damaged due to user error.
- Please use the product on flat areas such as polished floor, wooden floor or gym floor, rough ground will shorten the life of the PVC coating of the rope.
- In case of inconsistency in the recorded data after the first use or after replacing the batteries, you should re-pair the Smart Rope with the Şİmart App.
- Be careful when jumping with the PVC coated steel cable rope as there is a possibility of injury, it is also recommended that children under 10 years of age use the product under adult supervision.

LCD Display

- Press the push button to turn on the counter, the light will turn on.
 - Press and hold the push button for 2 seconds to switch between modes.
 - Press the push button twice to reset data in current mode.
 - Press and hold the push button for 8 seconds to reset the device.
- Note: If no action is taken for 10 seconds, the LCD display will turn off, the device will go into sleep mode after 5 minutes. If the button is pressed again, the counter will be reactivated.

LED Color Indicator

When the meter is turned on, the LED lights will turn on once, red, green and blue alternately.

Each of the colors represents a speed of your skipping rope.

- Red: ≥200 rpm (revolutions per minute)
- Green: 160 rpm (revolutions per minute)
- Blue: 100 rpm (revolutions per minute)

Using the App

- Download the Şİmart APP from the app stores or by scanning the QR code below.



- If your phone is Android OS, please enable Bluetooth GPS & Location permissions after installing the app.
 - Note: In order to pair an app with a BLE device via Bluetooth, Google requires smartphones on Android 6.0 version or higher to enable Location permissions. For more information you can also check Google's official site: <https://source.android.com/devices/bluetooth/ble>
 - Open the Şİmart App, enter your login details and launch the app. If you have not registered yet, you can register by clicking the "Register" button.
 - In the case of Smart Skipping Rope, the case will be automatically matched. You can browse the interface within the application to check the connection status.
 - "Added" information in the interface indicates that the pairing was successful.
 - "Failed to Add" information on the interface indicates that the match has failed. To resolve this issue, please click the "Add Device" button and add the device manually.
- Note: When the pairing is successful, the "Connected" icon will appear in the upper left corner of the LCD display.

USER MANUEL Smart Rope Skipping – ŞİMART Application

- To start skipping rope, select the skipping mode you want to use in the interface within the application.

Skipping Modes

- Press and hold the push button for 2 seconds to select the desired mode..
- You can also select modes from the app.

Free Training

- Skipping rope freely, there is no time or number limit.



The icon on the LCD display is shown in the picture.

Timing Training

- Set the time you want to skip.
- You can set the timer via the app.
- When the Smart Skipping Rope is used without the app, it will use the latest countdown setting set in the timer section in the app.



The icon on the LCD display is shown in the picture.

Counting Training

- Determine the total number you want to skip.
- You can set the number through the app.



The icon on the LCD display is shown in the picture.

USER MANUEL Smart Rope Skipping – ŞİMART Application

Offline Backup Function

When you don't run the app, your skipping data will be temporarily saved by the device and the data will be synced with the app when reconnected.

Counter Off/Reset

Press and hold the push button on the grip for 8 seconds, the counter will turn off. Press the push button again to reactivate the counter. When you want to reset the number of skipping and the timer, it will be enough to press the push button twice.

LED Light Settings

The LED light on the main hand grip turns on when we skipping rope. Each color Blue, Green, and Red represents the default speed of 100, 160, 200 rpm, respectively.

Recorded Data

Smart Skipping Rope not only records the calories burned and exercise time for that day, but also keeps track of longer-term data such as weekly, monthly, and yearly. This feature is very important for benchmarking and tracking your progress.

Battery Life

Smart Skipping Rope uses AAA LR03 1.5V batteries, which can last about 180 days under normal use. (Calculated based on a daily usage time of 15 minutes. The actual usage time depends on the frequency of use of the product). The batteries have a life expectancy of 350 days (our experiments were conducted under 25 °C temperature and 65% relative humidity). If the low battery icon appears on the screen, please replace the batteries with new ones. Please remove the batteries if you do not use the smart rope for a long time. If the product is not used for a long time, the AAA LR03 1.5V batteries inside may leak and damage the device.

Parameters

Dimensions	Φ37,5 x 168mm
Weight	180g
LCD Display	19,6 x 8,1mm
Battery	AAA LR03 1.5V x 2
Battery Life	90 hour
Max Skipping	9999 times
Max Time	99 minute 59 second
Min Skipping	1 time
Min Time	1 second
Auto Shutdown	5 minute



Waste electrical products should not be disposed of with household waste. Please recycle where facilities are available. Consult your local authority or dealer for recycling advice.

USER MANUEL Smart Rope Skipping – ŞİMART Application